



WWW.SEAGATE.COM

Visit us at our Support pages for assistance with

- **Installation:** Additional instructions and troubleshooting assistance
- **Knowledge Base:** FAQ's, How to use this product
- **Download Center:** Installation software, utilities, and diagnostics
- **Warranty Information**
- And all of your other storage needs

A soft copy of your comprehensive **User Guide** is included with your product.

To contact Support, visit us at our **Contact Us** page.



5 YEAR
LIMITED
WARRANTY

FCC DECLARATION OF CONFORMANCE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CLASS B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Any changes or modifications made to this equipment may void the user's authority to operate this equipment.

Seagate Technology LLC
920 Disc Drive
Scotts Valley, CA 95066
U.S.A.
www.seagate.com


©2009 Seagate Technology LLC. All rights reserved. Seagate, Seagate Technology, the Wave logo, and BlackArmor are trademarks or registered trademarks of Seagate Technology LLC or one of its affiliated companies in the United States and/or other countries. All other trademarks or registered trademarks are the property of their respective owners. Seagate reserves the right to change, without notice, product offerings or specifications.

PN: 100578525 06/09




KIT CONTENTS


AC Adaptor




USB Cable



Seagate BlackArmor WS 110 Drive




Stand




OPTIONAL

eSATA Cable





Cable not included.

1 Power




2 Connect



3 Install


After drive is connected, software installer automatically launches or double-click **Setup.exe** on drive. Visit <http://support.seagate.com/autorun> for additional instructions.



Follow the on-screen instructions.



RECOMMENDED: Create Recovery CD
Be sure to create a system recovery CD using BlackArmor Backup Software. Your system and data can be restored using this CD. See the *BlackArmor Backup User Guide* for instructions.



To begin the installation process using an eSATA cable, double-click the **My Computer** icon, then **BlackArmor Drive** to locate **Setup.exe**.